

Renfert

making work easy



SILENT flow sensor

NEW Sensor module for workbench extraction units

NEW SILENT flow sensor

Sensor module for workbench extraction units

Certified sensor module as an upgrade for workplace safety. A component to enhance safety for all the users not only those at NPM workplaces. The module prevents unnoticed loss of suction power and the resulting risk of health hazards.

Advantages

- Health protection ensured by monitoring the volume flow at the suction mouth.
- Acoustic and optical notification when the flow falls below the limit value, i.e. work safely at all times under optimum conditions!
- App-ready - updates and additional functions can be performed via the Renfert CONNECT app.

Details

- Easy to retrofit for certified Renfert extraction systems.
- Module for hazard analysis at workplaces (e.g. cobalt, non-precious metal).
- Easy cleaning option.



Compact mounting under the workbench

Technical data

Permissible mains voltage	100–240 V
Permissible mains frequency	50/60 Hz
Power consumption (<)	1 W // 1 VA
Weight	800 g // 28 oz
Dimensions (W x H x D)	107 x 200 x 95 mm // 4.2 x 7.9 x 3.7"
Ø suction fittings interior	45 mm // 2"
Ø suction fittings exterior	53 mm // 2"

Ordering information

SILENT flow sensor 100-240 V	No. 29140000
SILENT flow sensor 100-240 V Universal adapter	No. 29141000

